

Damper actuator for operating air control dampers in ventilation and air-conditioning systems for building services installations

- For air control dampers up to approx. 4 m²
- Torque 20 Nm
- Nominal voltage AC 100 ... 240 V
- · Control: Open-close or 3-point



| Technical data | | |
|---------------------|--------------------------------|--|
| Electrical data | Nominal voltage | AC 100 240 V, 50/60 Hz |
| | Nominal voltage range | AC 85 265 V |
| | Power consumption In operation | 2.5 @ nominal torque |
| | At rest | 0.6 W |
| | For wire sizing | 6 VA |
| | Connection | Cable 1 m, 3 x 0.75 mm ² |
| Functional data | Torque (nominal torque) | Min. 20 Nm @ nominal voltage |
| | Direction of rotation | Reversible with switch 0 🗸 or 1 🥕 |
| | Manual override | Gearing latch disengaged with pushbutton, self-resetting |
| | Angle of rotation | Max. 95° |
| | | by means of adjustable, mechanical end stops |
| | Running time | 150 s |
| | Sound power level | Max. 45 dB (A) |
| | Position indication | Mechanical, pluggable |
| Safety | Protection class | II Totally insulated □ |
| | Degree of protection | IP54 in any mounting position |
| | EMC | CE according to 89/336/EEC |
| | Low voltage directive | CE according to 73/23/EEC |
| | Mode of operation | Type 1 (to EN 60730-1) |
| | Ambient temperature range | −30 +50°C |
| | Non-operating temperature | −40 +80°C |
| | Ambient humidity range | 95% r.H., non-condensating (EN 60730-1) |
| | Maintenance | Maintenance-free |
| Dimensions / Weight | Dimensions | See «Dimensions» on page 2 |
| | Weight | Approx. 1'050 g |
| | | |

Safety notes



- The damper actuator is not allowed to be used outside the specified field of application, especially not in aircraft or any other form of air transport.
- · Caution: Power supply voltage!
- Assembly must be carried out by trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The cable must not be removed from the device.
- When calculating the required torque, the specifications supplied by the damper manufacturers (cross section, design, installation site), and the air flow conditions must be observed.
- The device contains electrical and electronic components and is not allowed to be disposed
 of as household refuse. All locally valid regulations and requirements must be observed.



Product features

Simple direct mounting Simple direct mounting on the damper spindle with a universal spindle clamp, supplied with

an anti-rotation strap to prevent the actuator from rotating.

Manual override Manual operation is possible with the self-resetting pushbutton (the gearing latch remains

disengaged as long as the pushbutton is pressed).

Adjustable angle of rotation with mechanical end stops. Adjustable angle of rotation

High functional reliability The actuator is overload-proof, requires no limit switches and automatically stops when the

end stop is reached.

Accessories

| | Description | Data sheet |
|------------------------|---|------------|
| Electrical accessories | Auxiliary switch SA | T2 - SA |
| | Feedback potentiometer PA | T2 - PA |
| Mechanical accessories | Various accessories (clamps, shaft extensions etc.) | T2 - Z-SMA |

3-point control


Electrical installation

Wiring diagrams

Note

Caution: Power supply voltage!


Other actuators can be connected in parallel. Please note the performance data.



Open-close control


Direction of rotation






Dimensions [mm]

Dimensional drawings








| Damper spindle | Length | <u>01</u> \$ |
|-----------------|---------|--------------|
| Clamp on top | min. 42 | 10 20 (26.7) |
| Clamp on bottom | min 20 | 10 20 |




















www.belimo.com



S1 S2 S3

